

ASSEMBLY INSTRUCTIONS

APPLIES TO:

Some Laundry Carts

- AL-51310 AL-55156
- AL-51311 AL-55154
 - AL-55155

PLEASE MAKE SURE ALL NUTS AND BOLTS ARE SECURE BEFORE PLACING CART INTO SERVICE.



Basket & Base/Caster Assembly

- 1 Place basket on top of base/casters and Align holes on basket with holes on base
- 2 Insert 1.5" bolts through basket and base Holes
- 3 Secure with 0.25" nylon lock nuts
- 4 If a pole rack is to be installed, tighten bolts securely
- 5 If a pole rack is to be installed, only finger tighten the basket to base/casters and proceed to step 3
- 4 Tighten all bolts securely



- secure w/ nuts (2)
- 4 Tighten all bolts securely

PARTS INCLUDED for some STANDARD CARTS & RACKS ACCESSORIES AVAILABLE (Call!) TOOLS REQUIRED x 4 0.5" bolts ¥1 basket x 4 0.5" nylon lock nuts 5 x1 tubular steel base w/ casters (Large) Č x2 double chrome tubes x1 single chrome tube 19/ x 1 crossbar pendant arm x1 x 4 bolts bolts x 2 x4 nuts x 2 nuts

info@alcosales.com

www.alcosales.com

(800)323-4282

secure with nut

center of basket

*Be sure arm faces toward