



19" wide from Side to Side

ALCO
Sales & Service Co.

TOILET SEAT

ALCO Sales & Service

800-323-4282 6851 High Grove Blvd. Burr Ridge, IL 60527

ADA Compliant Registration Number 4.23 ADAAG

Meets or exceeds

ASME / ANSI Z124.5

CSA

IAPMO / UPC



MADE IN THE U.S.A.



ALCO
Sales & Service Co.

Height
Adjustment
From
7.5" to 14"

See Our
Toilet Seat
on the back

Installation Instructions

MADE IN THE U.S.A.

www.alcosales.com

6 Easy Step-by-Step Instructions for Installing the Toilet Support

Step 1

For toilets that have a raised section at the bottom of the toilet bowl, remove the enclosed insert to allow for a tight fit.

For toilets that don't have a raised section at the bottom of the toilet bowl, put the insert into the grooves on the carriage.

Step 2

Remove liner from adhesive tape on the top of the carriage and place the Toilet Support in position under the toilet bowl.

DO NOT CAULK THE TOP OF THE CARRIAGE. MAKE SURE BOTTOM OF TOILET IS CLEAN BEFORE INSTALLING.

Step 3

With the Toilet Support under the bowl unscrew the leg to tighten it snugly against the floor.

DO NOT OVERTIGHTEN.

Step 4

Make sure the Toilet Support is mounted straight and that it is centered under the toilet.

Step 5

Wipe around the entire carriage and toilet where they meet, with the enclosed alcohol wipes, to remove any dirt.

Step 6

Apply a bead of the enclosed caulk around the entire Toilet Support carriage where it meets the toilet. Make sure to fill in all gaps.

Wipe off any excess with a damp cloth. Allow it to cure for 24 hours.

Once caulk has cured, leg can be raised to clean underneath it. Re-lower the leg after cleaning, making sure that it fits snugly.



TOLL FREE: 800-323-4282
www.alcosales.com