

AL-81976 AL-81977 AL-81978 AL-88779 AL-88781 AL-83229 AL-83230 AL-83231 AL-88780 AL-88782



SanipullBulk Premium[™] Quick Installation Guide for Washroom Nurse Call Pulls Scissors are needed to cut the Sanipull ribbon to optimal length (bandage scissors work great). Scissors are available to order. Attaching the Sanipull ribbon to the adapter 1. Withdraw from the bulk spool or coil sufficient Sanipull ribbon and cut to the optimum length. From the direction of the middle of the adapter insert the ribbon

Installation of Sanipull onto nurse call fixture

end under the plastic bridge found in the lower clamshell (look for guide arrows). Fold the ribbon back toward the adapter's bottom end. Close the lower clamshell door.

- 1. Cut the nurse call fixture's original pull string/cord about 4" below the wall fixture. Tie a Figure 8 knot at the end of it. Cut off excess. To resist pull through, a #6 stainless steel flat washer can be threaded onto the pull string before making the knot. Special hardware available at no cost.
- 2. Position the pull cord knot into the top clamshell, ensuring that it sits below the V-shaped notch. Close the upper clamshell door to secure.



Note: for **Austco™** pull cords the fixture's plastic snap connector must be cut off the end of the clear plastic lead. Melt the end of the lead to make a ball end. Insert the ball end into the top end of the clamshell adaptor, taking care that it sits below the V-shaped notch. Close the upper clasp door.



- 1. Insert the end of the ribbon into the slot at the top of the handle cover (install 2 covers, if 2 handles are used).
- 2. With the end of the ribbon positioned flush into the ribbon-profile recess of the bottom prong, pass ribbon over the next prong and weave under and over the next two prongs. (Ridges on one side of the prongs allow only one weave direction). A second grab handle can be installed mid-ribbon.
- 3. Slide the cover down over the ribbon-threaded posts to secure the grab handle.

Attaching a SuperSanipull spring clip to user-end of a Sanipull ribbon

- 1. Hold the clip upside down. Position the end of the ribbon over the center of the clip pointing toward the clasp. Following the guide arrow, insert the ribbon under the bridge until the end butts against the end of the clasp.
- 2. Fold the ribbon back toward the clasp end and close the clamshell door.
- 3. Attach spring clip onto linen, clothing, around bed rail or wheelchair arm rest.

Sanitize Sanipulls after installation and regularly according to facility housekeeping policy.





There are two styles of grab handle available for optimum accessibility: open (AL-82123A) and closed (AL-82123C). Handles with covers are packaged in bags of 10 sets.





SuperSanipull spring clips are ordered in bags of 10 as AL-82121

info@alcosales.com

800.323.4282

www.alcosales.com