

## ASSEMBLY INSTRUCTIONS

## AL-56735 LARGE CAPACITY UTILITY CART



## TOOLS REQUIRED: Large standard (flat screwdriver), 3/4" socket-wrench & two-7/16" open end (or box end) wrenches.

- 1) Attach left frame to right frame using the short cross bars ( supplied with threaded inserts ), 2 for top and 2 for bottom, with the  $\frac{5}{16}$ " x  $1^{1}/2$ " bolts ( 4 for top and 4 for bottom 8 total ). Note The welded wires on cross bars face inward and the brackets downward. Then beneath each of the original  $\frac{5}{16}$ " bolts, place and secure a  $\frac{1}{4}$ " x  $1^{1}/2$ " bolt (8 total).
- 2) Attach the 2 remaining short cross bars (caps at each end), across the middle of the frames, top and bottom. These will attach beneath the long frame bars using  $\frac{1}{4}$ " x 2  $\frac{1}{4}$ " bolts (4 total).
- 3) Attach the handle using  $\frac{1}{4}$ " x 2  $\frac{1}{4}$ " bolts (4 total).
- 4) To attach large rear wheels, place axle through rear legs then add wheels and secure with cotter pins.
- 5) To attach front wheels, use the  $^1/_4$ " x  $1^1/_8$ " bolts with  $^1/_4$ " nylon locking nuts (4 each).

## **WARNING**

- Never allow anybody to ride in or on cart.
- Always proceed slowly. Be sure wheels roll free and turn easily.
- Place all loads in center of basket for balance.
- Maximum capacity per basket: 25 pounds.

