


NOTE: This internal schematic diagram is being provided simply as a guide to the internal wiring and components inside the AL-66034 push/pull station. Any modifications and/or alterations to this station or its use in a system other than a TekTone[®] compatible nurse-call system will void its warranty and UL Listing. Neither ALCO Sales nor TekTone[®] will be responsible for any such unauthorized use.



INSTALLATION GUIDELINES and GENERAL INFORMATION:

1. See the specific system wiring diagram for the balance of the wiring connections required.
2. Wiring connections and terminals may not be in the same order as they appear on the equipment.
3. Observe all local and national electrical and building codes.
4. Please note that any use of the AL-66034 station with systems other than the NC110A, NC110N, NC150N and/or NC200N will most likely void any U.L. Listing for this component.

Phone: 800-323-4282

Fax: 800-950-1167



Like us on Facebook at:
www.facebook.com/ALCOSalesServiceCo

Follow us on Twitter at:
www.twitter.com/ALCOSales

info@alcosales.com

www.alcosales.com