ALCO Sales & Service Co. 800.323.4282 www.alcosales.com info@alcosales.com



## Assembly instructions for IV Poles

Tools you will need for assembly:

- 9/16" Flat Wrench
- 1. You should receive in your shipment:
  - a. Base
  - b. Pole
  - c. Threadlocker
  - d. Top



- 2. Remove all packing material and unscrew Bolt and Washer from the bottom of (b. Pole).
- 3. Insert bottom of Pole into hole on top of (a. Base)
- 4. Open (c. Threadlocker) and apply generous amount to threads on Bolt that was removed from bottom of pole.
- 5. With tooth washer on bolt insert bolt in small hole in middle of (a. Base) from the bottom. Tighten Bolt with 9/16" Wrench. Ensure pole is firmly seated and bolt is tightened as much as possible with wrench.
- 6. To add top, slide top over top of inner pole. Squeeze buttons with fingers and slide top down. Line up holes so buttons pop through holes in (d. top).
- 7. Let pole stand for 4-6 Hours for threadlocker to set.
- 8. Your new IV Pole is now ready for use.