



RESOURCES

CATALOGS

CLEARANCE

Stryker M-Series Parts

Keep your Stryker stretchers in service with replacement parts built for the job. From repairs to routine maintenance, find the parts you need to keep stretchers functional, reduce downtime, and avoid unnecessary replacements.



Common
Replacement Parts



Constant Descent Jacks



8" Caster Assembly



Brake Rod Assembly



Fifth Wheel Assembly



Siderail Assembly

M-SERIES STRETCHER PADS

FOLLOW US



Questions? Contact us today 800-323-4282 | 630-655-1900

For California residents only: ⚠ WARNING:
Cancer and Reproductive Harm - www.P65Warnings.ca.gov