

## How To Install Heel Loops

1. Identify the parts of the heel loop.



2. Separate the down tube from the hanger of the footrest or legrest.



3. Drill a hole slightly bigger than the screw.



**4. Insert the post through the small loop at the end of the heel loop.**



**5. Insert the screw through the bottom of the footplate.**



**6. Slide the large loop at the end of the heel loop over the end of the down tube.**



**7. Bolt the screw into the post of the heel loop.**



**8. Tighten the screw with an Allen wrench.**



**9. The heel loop is now installed.**



**10. Install the down tube back into the hanger. Repeat this procedure for the other side.**



**ALCO**<sup>®</sup>  
Sales & Service Co.

Customer Service | 800.323.4282 | [www.alcosales.com](http://www.alcosales.com) | [info@alcosales.com](mailto:info@alcosales.com)