

HAND SANITIZING STATION AL-88529

No contact, No contamination!



FEATURES

- Hand Sanitizer Station simple & easy to use
- No contact with hands
- Heavy Duty Stand
- Compatible with hand sanitizer and hand sanitizer gel
- Rust proof durable powder coated aluminum with steel base
- · Hand Sanitizer is easy to refill with any soap
- Optional customize with logo, welcome message, or use instructions, additional cost applies

TECHNICAL SPECS

- Stand
 - Height: 4'
 - Width: 8"
- Base:
 - Weight-14 lb
 - Width- 15.75"
- Hand Sanitizer:
 - Height- 10"
 - Width- 4"
- Charger or Batteries:
 - Charger- 6V, 1 Amp
 - Batteries 4 C Batteries



Fill with any soap!



HAND SANITIZING STATION

INSTALLATION AND USE



STEP 1
Attach rod to base using a countersunk bolt and tighten with the Allen key



STEP 3
Remove Soap Dispenser



STEP 5
Attach nut to the otherside of the stand



STEP 7
Pour any kind of liquid/gel hand sanitizer into soap dispenser



STEP 2 Open the Hand Sanitizer with opening clip



STEP 4
Screw the back of Hand Sanitizer to the stand with a screwdriver



STEP 6
Use adjustable wrench and screwdriver to tighten as needed



STEP 9
Shut lid of the hand sanitizer to complete installization.