

AL-89798-0212 Respiratory Hygiene Station - Locking



Accessories (shown below, each sold separately):

- Sign Holder Vertical Respiratory Hygiene Station
- Sign Holder Horizontal Respiratory Hygiene Station
- Floor Stand All Steel (Quartz Beige)

Related Products (sold as kits):

- Cover Your Cough Compliance Kit
 - Respiratory Hygiene Station Locking
 - Floor Stand All Steel
 - Sign Holder Vertical
- Cover Your Cough Compliance Kit
 - Respiratory Hygiene Station Locking
 - Floor Stand All Steel
 - Sign Holder Horizontal
- Cover Your Cough Compliance Kit
 - Respiratory Hygiene Station Locking
 Size Helder Verticel
 - Sign Holder Vertical
 - Cover Your Cough Compliance Kit
 - Respiratory Hygiene Station Locking
 - Sign Holder Horizontal

Product Description:

- Respiratory Hygiene Station Locking
- Holds two boxes of face masks, one or two boxes of facial tissues
 or one box of gloves, and one hand sanitizer dispenser
- Hinged locking lid
- Keyholes and screw holes for wall mounting or can be mounted to a floor stand
- Quartz Beige ABS Plastic

Primary Area for Product Usage:

- All ports of entry
- · Anywhere respiratory hygiene products are needed

Dispenses:

- Left: Dispensing unit no larger than 8.50"W x 14.75"H x 5.00"D (21.6 cm x 37.5 cm x 12.7 cm)
- [Note: Refer to automatic dispensing specifications on detection distance requirements.]
- Middle: Box(es) no larger than 8.00"W x 4.88"H x 4.75"D (20.3 cm x 12.4 cm x 12.1 cm)
- Right: Box(es) no larger than 5.50"W x 9.75"H x 4.75"D (13.7 cm x 25.4 cm x 12.1 cm)

Package Specifications:

- Package Quantity: 1 per case
- 24"L x 16"W x 6"H (61.0 cm x 40.6 cm x 15.2 cm)
- 5.0 lbs (2.3 kg) approximated

Product Specifications (overall external dimensions):

- 22.25"W x 14.85"H x 5.00"D (56.5 cm x 37.7 cm x 12.7 cm)
- 2.7 lbs (1.2 kg) approximated

Mounting Specifications:



ALCO[®] Sales & Service Co.

AL-89798-0212 Respiratory Hygiene Station - Locking Installation Instructions/Material Care & Construction

Installation

Always mount dispensers securely prior to loading with product.



- Mount securely to a wall with screws approved and supplied by building maintenance.
- It can also be mounted to a Floor Stand (sold separately).





Parts included:

Dispenser

Tools Required:

No tools required to assemble dispenser

Care and Construction ABS Plastic

Material Characteristics

Designed for Long-Term Heavy-Duty Applications

The combination of copolymers (Acrylonitrile, Butadiene, and Styrene) gives ABS an excellent combination of strength, rigidity, and toughness.

ABS is chemical and stress-crack resistant. It is tough, dimensionally stable, and will hold up to long-term use. It possesses high strength and performance characteristics at a reasonable cost.

Care and Cleaning

Use mild soap and water to clean. Petroleum-based oils, solvents, and paints should not be used.

Standard hospital cleaning supplies can be used.

AL-89798-0233



Signature Series Respiratory Hygiene Station - Locking



Accessories (shown below, each sold separately):

- · Sign Holder Vertical Respiratory Hygiene Station
- Sign Holder Horizontal Respiratory Hygiene Station
- KS010-0420, Floor Stand All Steel (Black)

Related Products (sold as kits):

- Cover Your Cough Compliance Kit
 - Respiratory Hygiene Station Locking, Cherry
 - Floor Stand All Steel (Black)
 - Sign Holder Vertical
 - Cover Your Cough Compliance Kit
 - Respiratory Hygiene Station Locking, Cherry
 - Floor Stand All Steel (Black)
 - Sign Holder Horizontal



Product Description:

- Respiratory Hygiene Station Locking
- Holds two boxes of face masks, one or two boxes of facial tissues or one box of gloves, and one hand sanitizer dispenser
- Hinged locking lid
- Keyholes and screw holes for wall mounting or can be mounted to a f oor stand
- Signature Series Made of Cherry Fauxwood ABS Plastic (also available in Maple Fauxwood ABS Plastic)

Primary Area for Product Usage:

 Emergency and admitting departments, all ports of entry, outpatient radiology/MRI, outpatient labs and pharmacies

Dispenses:

- Most major manufacturers' standard boxes
- Left: One hand sanitizing gel or foam dispenser mountable area 8.50[°]W x 14.75[°]H x 5.00[°]D (21.6 cm x 37.5 cm x 12.7 cm) [Note: Refer to automatic dispensing specifications on detection distance requirements.]
- Middle: Two boxes of face masks no larger than 8.00[°]W x 4.88[°]H x 4.75[°]D (20.3 cm x 12.4 cm x 12.1 cm)
- Right: One large or two small boxes of tissues or one box of gloves no larger than 5.50[°]W x 9.75[°]H x 4.75[°]D (13.7 cm x 25.4 cm x 12.2 cm)

Package Specifications:

- Package Quantity: 1 per case
- 24"L x 16"W x 6"H (61.0 cm x 40.6 cm x 15.2 cm)
- 6.0 lbs (2.7 kg) approximated

Product Specifications (overall external dimensions):

- 22.25[°]W x 14.75[°]H x 5.00[°]D (56.5 cm x 37.5 cm x 12.7 cm)
- 3.6 lbs (1.6 kg) approximated

Mounting Specifications:



AL-89798-0233 **Respiratory Hygiene Station - Locking** Installation Instructions/Material Care & Construction

Installation

Sales & Service C

Always mount dispensers securely prior to loading with product.

- Attach the hand sanitizer dispenser first. • Do NOT load sanitizer until after dispenser is mounted to a wall or stand. Mounting holes 0 0 for hand sanitizer o
 - · Mount securely to a wall with screws approved and supplied by building maintenance.
 - It can also be mounted to a Floor Stand (sold separately).



Parts included:

- Dispenser
- **Tools Required:**
 - No tools required to assemble dispenser

Care and Construction Fauxwood ABS Plastic

Material Characteristics

Designed for Long-Term Heavy-Duty Applications

The combination of copolymers (Acrylonitrile, Butadiene, and Styrene) gives ABS an excellent combination of strength, rigidity, and toughness. The fauxwood finish is ARVINYL laminate created from a semi-rigid film.

ABS is chemical and stress-crack resistant. It is tough, dimensionally stable, and will hold up to long-term use. To ensure product longevity, fauxwood products should not be mounted in very hot or cold areas.

Our fauxwood material is engineered to have a natural grain appearance both in Cherry and Maple finishes. The two color choices provide a visually appealing, upscale option to any area.

Care and Cleaning

Signature Series products can be cleaned with standard hospital cleaning products. Petroleum-based oils, solvents, and paints should not be used. Standard hospital cleaning supplies are approved for use on our fauxwood products.



AL-89798-0412 Respiratory Hygiene Station – Locking



Related Products (each sold separately):

- Floor Stand All Steel
- Floor Stand
- Sign Holder Vertical (shown below)
- Sign Holder Horizontal (shown below)





Product Description:

- Respiratory Hygiene Station Locking
- Holds two boxes of face masks, one or two boxes of facial tissues or one box of gloves, and one hand sanitizer dispenser
- Hinged locking lid
- Keyholes and screw holes for wall mounting or can be mounted to a floor stand
- Quartz Beige Powder-Coated Steel

Primary Area for Product Usage:

- All ports of entry
- · Anywhere respiratory hygiene products are needed

Dispenses:

- Left: One hand sanitizing gel or foam dispenser no larger than $8.35"W\ x\ 14.75"H\ x\ 5.00"D\ (21.2\ cm\ x\ 37.5\ cm\ x\ 12.7\ cm)$
- [Note: Refer to automatic dispensing specifications on detection distance requirements.]
- Middle: Box(es) no larger than 8.00"W x 9.50"H x 4.75"D (20.3 cm x 24.1 cm x 12.1 cm)
- Right: Box(es) no larger than 5.50"W x 9.50"H x 4.75"D (13.7 cm x 24.1 cm x 12.1 cm)

Package Specifications:

- Package Quantity: 1 per case
- 24"L x 16"W x 6"H (61.0 cm x 40.6 cm x 15.2 cm)
- 9.0 lbs (4.1 kg) approximated

Product Specifications (overall external dimensions) :

- 22.31"W x 14.78"H x 5.17"D (56.7 cm x 37.5 cm x 13.1 cm)
- 6.7 lbs (3.0 kg) approximated

Mounting Specifications:





Installation

Always mount dispensers securely prior to loading with product.



- Mount securely to a wall with screws approved and supplied by building maintenance.
- It can also be mounted to a Floor Stand (sold separately).



Parts included:

Dispenser

Tools Required:

No tools required to assemble dispenser

Care and Construction

Powder-Coated Steel

Material Characteristics

Designed for Long-Term Use

Our steel dispensers and stands are coated with polyester powders which makes them highly resistant to corrosion.

Powder-coated steel is ideal for dispensers used in a healthcare or an industrial setting because it is impact resistant and is not effected by extremes in temperature.

Dispensers and stands made of powder-coated steel are both attractive and functional, providing years of service.

Care and Cleaning

The powder coated finish resists common chemicals and cleaning agents and can be easily wiped clean with soap and water.