

AL-88783 Installation Instructions

Sanipull Ball Chain Adapter

1. Attach the Ball Chain Adapter to the end of the fixture ball chain 1-3 balls sit below the V-shaped notch in the middle of the chamber (Fig 1)
2. Universal Sanipull Clip is attached to the Ball Chain Adapter providing 13 ± 1 lb release force to protect fixtures and pull switch from over-force damage (Fig 2)



Fig. 1



Fig. 2

Ball Chain Adapter is designed to mate with Universal Sanipull Clip. Switch/fixture protection will be compromised and product's lifetime warranty is void if Sanipull fittings are used with a non-approved pull medium.

