


ASSEMBLY INSTRUCTIONS

PLEASE MAKE SURE ALL NUTS AND BOLTS ARE SECURE BEFORE PLACING HAMPER INTO SERVICE.




1

Caster & Base Assembly

- 1 Insert casters (4) into the base legs
- 2 Place 1 lock washer under base tube and one on top.
- 3 Slide smaller wrench between base and caster to hold in place, then use the larger wrench to tighten acorn nut until secure. (wrenches supplied)


**locking casters should be in front near foot pedal.*



2

Upright Installation

- 1 Insert vertical male poles (2) into female base tubes.



3

Lid Installation

- 1 Place female tubes onto vertical male poles.

4



Pedal Wire Installation

- 1 Using hinged pedal wires (2) place one end through hole located at the back of the lid,
- 2 Insert hanging end through holes located on base. Hole selection will determine lid opening height.

**Be sure pedal wire ends are pointing inward.*

PARTS INCLUDED for 200 SERIES CARTS AND RACKS, 56, 91

1 x8 lock washers
x4 acorn nuts
x2 locking casters
x2 casters

2 x2 chrome tubes
 x1 base w/ foot pedal

3 x1 lid

4 x2 hinged pedal wires

ACCESSORIES AVAILABLE

NEED A BAG?

Plastics Bags Call!
Nylon Bags

TOOLS INCLUDED

